

# Instruction of Testing Camera by Dedicated SDK


Please supply proper POWER to camera

Please make sure SERIAL PORT of PC can work properly, DO NOT use USB port to Serial Port convertor, please connect the camera to the Serial Port of computer directly

1. Uncompress




2. Double Click and Open



3.

3.1 Select Picture Size, 160x120, 320x240, 640x480 optional for 0.3Megapixel camera, 160x120, 320x240, 640x480, 1280x1024 optional for 1.3Megapixel camera



3.2 Select Serial Port

3.3 Select Baud Rate

3.4 Click "Open Port"

3.5 Select Datasheet  
Please select the last one

3.6 Enter ID No. if necessary

3.6 Click this button to capture a single picture

3.7 Click this button to capture several pictures continuously

3.8 Click this button to stop capturing picture

3.9 Picture will display in this window after click the button "Snapshot" and "Snapshot Continuously"