

Explorer MAX

—Assembly Instruction



Product Name : Explorer Max
SKU : ROB0137
Company : DFRobot. Shanghai Zhiwei Robotics Corp. Ltd
Address : Rm 615,Bld. Y1,No.112 Liangxiu Rd,Pudong,Shanghai,China
Telephone : 86-21-61620183
Fax : 86-21-61001657
Email : service@dfrobot.com
Http : www.DFRobot.com




- ◎ The product uses battery of 4×1.5V AA.
- ◎ Designs and specifications are subject to change without notice.
- ◎ All final explanation rights within the scope prescribed by law belong to DFRobot.




- Please log in DFRobot official website : (www.dfrobot.com), searching ROB0137 in Product Wiki for more documents and tutorials to learn.


13 Quick Start Guide



Mode 1





Mode 2




Mode 3


Mode 4




01 Motor Installation




02 Wheel Installation




03 Roller wheel Installation




04 Line-tracking Sensor Installation




05 Main Board Installation




06 Multifunctional Mount Installation




07 Ultrasonic Sensor Mount Installation




08 Ultrasonic & Light 2 in 1 Sensor Installation




09 RGB LED Display Panel Installation



10 Electric Circuit Connection/Connection Diagram



12 Top Cover Installation



11 Battery Holder Installation

